

NOTE: FOR WIRE SIZES #14, #12 AND #10.

STEP 1

1/2"

STRIP WIRES APPROXIMATELY 1/2" FROM ENDS AND TWIST ENDS TOGETHER.

STEP 2

TWIST WIRE NUT ONTO WIRE ENDS.

STEP 3

PUSH WIRE NUT INTO CONNECTOR PAST TABS.

TABS

STEP 4

STEP 5

STRAP TOP CONNECTOR

G

WIRE CONNECTION

NTS

3M-DBY/DBR

